

## **SECTION 040120 - BRICK MASONRY REPAIR**

### **PART 1 - GENERAL**

#### **1.1 SUMMARY**

- A. Section includes repairing brick masonry.

#### **1.2 DEFINITIONS**

- A. Rebuilding (Setting) Mortar: Mortar used to set and anchor masonry in a structure, distinct from pointing mortar installed after masonry is set in place.

#### **1.3 PREINSTALLATION MEETINGS**

- A. Preinstallation Conference: Conduct conference at Project site.

#### **1.4 ACTION SUBMITTALS**

- A. Product Data: For each type of product.
- B. Shop Drawings:
  - 1. Include plans, elevations, sections, and locations of replacement bricks on the structure.
  - 2. Show provisions for expansion joints or other sealant joints.
- C. Samples: For each exposed product and for each color and texture specified.

#### **1.5 INFORMATIONAL SUBMITTALS**

- A. Quality-control program.

#### **1.6 QUALITY ASSURANCE**

- A. Brick Masonry Repair Specialist Qualifications: Engage an experienced brick masonry repair firm to perform work of this Section. Firm shall have completed work similar in material, design, and extent to that indicated for this Project with a record of successful in-service performance. Experience in only installing masonry is insufficient experience for masonry repair work.
- B. Quality-Control Program: Prepare a written quality-control program for this Project to systematically demonstrate the ability of personnel to properly follow methods and use

materials and tools without damaging masonry. Include provisions for supervising performance and preventing damage.

- C. Mockups: Prepare mockups of brick masonry repair to demonstrate aesthetic effects and to set quality standards for materials and execution and for fabrication and installation.
  - 1. Masonry Repair: Prepare sample areas for each type of masonry repair work performed. If not otherwise indicated, size each mockup not smaller than two adjacent whole units or approximately 48 inches in least dimension. Construct sample areas in locations in existing walls where directed by Architect unless otherwise indicated. Demonstrate quality of materials, workmanship, and blending with existing work.

## **PART 2 - PRODUCTS**

### **2.1 MASONRY MATERIALS**

- A. Face Brick: As required to complete brick masonry repair work.
  - 1. Brick Matching Existing: Units with colors, color variation within units, surface texture, size, and shape that match existing brickwork.
    - a. Physical Properties: According to ASTM C67 and as follows:
      - 1) Color & Texture: Match existing brick.
      - 2) Grade: SW.
      - 3) Type: FBX
      - 4) Unit Compressive Strength: Provide units with minimum average net-area compressive strength of 3350 psi
      - 5) Initial Rate of Absorption: Less than 30 g/30 sq. in. per minute when tested according to ASTM C 67.
      - 6) Efflorescence: Provide brick that has been tested according to ASTM C 67 and is rated "not effloresced."
      - 7) Size (Approximate): 3-5/8 inches wide by 2-1/4 inches high by 7-5/8 inches long,
    - b. For existing brickwork that exhibits a range of colors or color variation within units, provide brick that proportionally matches that range and variation rather than brick that matches an individual color within that range.
  - 2. Special Shapes:
    - a. Provide molded, 100 percent solid shapes for applications where core holes or "frogs" could be exposed to view or weather when in final position and where shapes produced by sawing would result in sawed surfaces being exposed to view.
    - b. Provide specially ground units, shaped to match patterns, for arches and where indicated.
    - c. Mechanical chopping or breaking brick, or bonding pieces of brick together by adhesive, are unacceptable procedures for fabricating special shapes.

## 2.2 MORTAR MATERIALS

- A. Portland Cement: ASTM C150, Type I or Type II, except Type III may be used for cold-weather construction; white or gray, where required for color matching of mortar.
  - 1. Provide cement containing not more than 0.60 percent total alkali when tested according to ASTM C114.
- B. Hydrated Lime: ASTM C207, Type S.
- C. Masonry Cement: ASTM C91/C91M.
  - 1. Manufacturers: Subject to compliance with requirements, provide products by one of the following:
    - a. Lafarge North America Inc.
    - b. Lehigh Hanson; Heidelberg Cement Group.
    - c. An approved equal
- D. Mortar Sand: ASTM C144.
  - 1. Exposed Mortar: Match size, texture, and gradation of existing mortar sand as closely as possible. Blend several sands if necessary to achieve suitable match.
  - 2. Colored Mortar: Natural sand or ground marble, granite, or other sound stone of color necessary to produce required mortar color.
- E. Mortar Pigments: ASTM C979, compounded for use in mortar mixes, and having a record of satisfactory performance in masonry mortars.
- F. Water: Potable.

## 2.3 MANUFACTURED REPAIR MATERIALS

- A. Brick Patching Compound: Factory-mixed cementitious product that is custom manufactured for patching brick masonry.
  - 1. Use formulation that is vapor and water permeable (equal to or more than the brick), exhibits low shrinkage, has lower modulus of elasticity than bricks being repaired, and develops high bond strength to all types of masonry.
  - 2. Formulate patching compound in colors and textures to match each brick being patched.

## 2.4 ACCESSORY MATERIALS

- A. Setting Buttons and Shims: Resilient plastic, non-staining to masonry, sized to suit joint thicknesses and bed depths of bricks, less the required depth of pointing materials unless removed before pointing.
- B. Other Products: Select materials and methods of use based on the following, subject to approval of a mockup:

1. Previous effectiveness in performing the work involved.
2. Minimal possibility of damaging exposed surfaces.
3. Consistency of each application.
4. Uniformity of the resulting overall appearance.
5. Do not use products or tools that could leave residue on surfaces.

## 2.5 MORTAR MIXES

- A. Measurement and Mixing: Measure cementitious materials and sand in a dry condition by volume or equivalent weight. Do not measure by shovel; use known measure. Mix materials in a clean, mechanical batch mixer.
- B. Colored Mortar: Produce mortar of color required by using specified ingredients. Do not alter specified proportions without Architect's approval.
  1. Mortar Pigments: Where mortar pigments are indicated, do not add pigment exceeding 10 percent by weight of the cementitious or binder materials, except for carbon black which is limited to 2 percent.
- C. Do not use admixtures in mortar unless otherwise indicated.
- D. Mortar for Unit Masonry: Comply with ASTM C 270, Proportion Specification. Provide the following types of mortar for applications stated unless another type is indicated or needed to provide required compressive strength of masonry.
  1. For masonry below grade or in contact with earth, use Type S.
  2. For reinforced masonry, use Type M.
  3. For mortar parge coats, use Type S.
  4. For exterior, above-grade, load-bearing and nonload-bearing walls and parapet walls; for interior load-bearing walls; for interior nonload-bearing partitions; and for other applications where another type is not indicated, use Type N.
  5. For interior nonload-bearing partitions, Type O may be used instead of Type N.

## PART 3 - EXECUTION

### 3.1 PROTECTION

- A. Remove downspouts adjacent to masonry and store during masonry repair. Install new when repairs are complete.
  1. Provide temporary rain drainage during work to direct water away from building.

### 3.2 BRICK REMOVAL AND REPLACEMENT

- A. At locations indicated, remove bricks that are damaged, spalled, or deteriorated. Carefully remove entire units from joint to joint, without damaging surrounding masonry, in a manner that permits replacement with full-size units.
- B. Support and protect remaining masonry that surrounds removal area.
- C. Maintain flashing, reinforcement, lintels, and adjoining construction in an undamaged condition.
- D. Notify Architect of unforeseen detrimental conditions including voids, cracks, bulges, and loose units in existing masonry backup, rotted wood, rusted metal, and other deteriorated items.
- E. Remove in an undamaged condition as many whole bricks as possible.
  - 1. Remove mortar, loose particles, and soil from brick by cleaning with hand chisels, brushes, and water.
  - 2. Remove sealants by cutting close to brick with utility knife and cleaning with solvents.
- F. Clean masonry surrounding removal areas by removing mortar, dust, and loose particles in preparation for brick replacement.
- G. Replace removed damaged brick with other removed brick in good condition, where possible, matching existing brick. Do not use broken units unless they can be cut to usable size.
- H. Install replacement brick into bonding and coursing pattern of existing brick. If cutting is required, use a motor-driven saw designed to cut masonry with clean, sharp, unchipped edges.
  - 1. Maintain joint width for replacement units to match existing joints.
  - 2. Use setting buttons or shims to set units accurately spaced with uniform joints.
- I. Lay replacement brick with rebuilding (setting) mortar and with completely filled bed, head, and collar joints. Butter ends with enough mortar to fill head joints and shove into place. Wet both replacement and surrounding bricks that have ASTM C67 initial rates of absorption (suction) of more than 30 g/30 sq. in. per min. Use wetting methods that ensure that units are nearly saturated but surface is dry when laid.
  - 1. Tool exposed mortar joints in repaired areas to match joints of surrounding existing brickwork.
  - 2. Rake out mortar used for laying brick before mortar sets according to Section 040120.64 "Brick Masonry Repointing." Point at same time as repointing of surrounding area.
  - 3. When mortar is hard enough to support units, remove shims and other devices interfering with pointing of joints.
- J. Curing: Cure mortar by maintaining in thoroughly damp condition for at least 72 consecutive hours, including weekends and holidays.

1. Hairline cracking within the mortar or mortar separation at edge of a joint is unacceptable. Completely remove such mortar and repoint.
2. Keep each layer damp for 72 hours or until patching compound has set.

### 3.3 FINAL CLEANING

- A. After mortar has fully hardened, thoroughly clean exposed masonry surfaces of excess mortar and foreign matter; use wood scrapers, stiff-nylon or -fiber brushes, and clean water, applied by low pressure spray.
  1. Do not use metal scrapers or brushes.
  2. Do not use acidic or alkaline cleaners.

END OF SECTION 040120

## **SECTION 040121 - BRICK MASONRY REPOINTING**

### **PART 1 - GENERAL**

#### **1.1 SUMMARY**

- A. Section includes repointing joints with mortar.

#### **1.2 UNIT PRICES**

- A. Work of this Section is affected by unit prices specified in Section 012200 "Unit Prices."

#### **1.3 PREINSTALLATION MEETINGS**

- A. Preinstallation Conference: Conduct conference at Project site.

#### **1.4 ACTION SUBMITTALS**

- A. Product Data: For each type of product.
- B. Samples: For each exposed product and for each color and texture specified.

#### **1.5 INFORMATIONAL SUBMITTALS**

- A. Quality-control program.

#### **1.6 QUALITY ASSURANCE**

- A. Brick Masonry Repointing Specialist Qualifications: Engage an experienced brick masonry repointing firm to perform work of this Section. Firm shall have completed work similar in material, design, and extent to that indicated for this Project with a record of successful in-service performance. Experience in only installing masonry is insufficient experience for masonry repointing work.
- B. Quality-Control Program: Prepare a written quality-control program for this Project to systematically demonstrate the ability of personnel to properly follow methods and use materials and tools without damaging masonry. Include provisions for supervising performance and preventing damage.

- C. Mockups: Prepare mockups of brick masonry repointing to demonstrate aesthetic effects and to set quality standards for materials and execution.
  - 1. Repointing: Rake out joints in two separate areas, each approximately 36 inches high by 48 inches wide, unless otherwise indicated, for each type of repointing required, and repoint one of the areas.

## **PART 2 - PRODUCTS**

### **2.1 MORTAR MATERIALS**

- A. Portland Cement: ASTM C150, Type I or Type II, except Type III may be used for cold-weather construction; white or gray, where required for color matching of mortar.
  - 1. Provide cement containing not more than 0.60 percent total alkali when tested according to ASTM C114.
- B. Hydrated Lime: ASTM C207, Type S.
- C. Masonry Cement: ASTM C91. Type 1 Portland Cement
- D. Mortar Sand: ASTM C144.
  - 1. Match size, texture, and gradation of existing mortar sand as closely as possible. Blend several sands if necessary to achieve suitable match.
  - 2. Color: Provide natural sand or ground marble, granite, or other sound stone of color necessary to produce required mortar color.
- E. Mortar Pigments: ASTM C979, compounded for use in mortar mixes, and having a record of satisfactory performance in masonry mortars.
  - 1. For exposed mortar, select materials (complying with the requirements) and proportion pigments with other ingredients as necessary to match the color and texture of existing corresponding materials. White Portland cement and colored aggregates similar to the existing may be used as required to accomplish the matching of mortar color desired.
- F. Water: Potable.

### **2.2 MORTAR MIXES**

- A. Measurement and Mixing: Measure cementitious materials and sand in a dry condition by volume or equivalent weight. Do not measure by shovel; use known measure. Mix materials in a clean, mechanical batch mixer.



1. Mixing Pointing Mortar: Thoroughly mix cementitious materials and sand together before adding any water. Then mix again, adding only enough water to produce a damp, unworkable mix that retains its form when pressed into a ball. Maintain mortar in this dampened condition for 15 to 30 minutes. Add remaining water in small portions until mortar reaches desired consistency. Use mortar within one hour of final mixing; do not retemper or use partially hardened material.
- B. Colored Mortar: Produce mortar of color required by using specified ingredients. Do not alter specified proportions without Architect's approval.
  1. Mortar Pigments: Where mortar pigments are indicated, do not add pigment exceeding 10 percent by weight of the cementitious or binder materials, except for carbon black which is limited to 2 percent.
- C. Do not use admixtures in mortar unless otherwise indicated.
- D. Mixes: Mix mortar materials in the following proportions:
  1. Pointing Mortar by Volume: ASTM C270, Proportion Specification, 1 part portland cement, 1 part lime, and 6 parts sand. Add mortar pigments to produce mortar colors required.

### **PART 3 - EXECUTION**

#### **3.1 PROTECTION**

- A. Remove gutters and downspouts and associated hardware adjacent to masonry and store during masonry repointing. Reinstall when repointing is complete.
  1. Provide temporary rain drainage during work to direct water away from building.

#### **3.2 REPOINTING**

- A. Rake out and repoint joints to the following extent:
  1. All joints in areas indicated.
  2. Joints indicated as sealant-filled joints. Seal joints according to Section 079200 "Joint Sealants."
  3. Joints at locations of the following defects:
    - a. Holes and missing mortar.
    - b. Cracks that can be penetrated 1/4 inch more by a knife blade 0.027 inch thick.
    - c. Cracks 1/8 inch or more in width and of any depth.

- d. Hollow-sounding joints when tapped by metal object.
  - e. Eroded surfaces 1/4 inch or more deep.
  - f. Deterioration to point that mortar can be easily removed by hand, without tools.
  - g. Joints filled with substances other than mortar.
- B. Do not rake out and repoint joints where not required.
- C. Rake out joints as follows, according to procedures demonstrated in approved mockup:
  - 1. Remove mortar from joints to depth of 2 times joint width. Do not remove unsound mortar more than 2 inches deep; consult Architect for direction.
  - 2. Remove mortar from brick and other masonry surfaces within raked-out joints to provide reveals with square backs and to expose masonry for contact with pointing mortar. Brush, vacuum, or flush joints to remove dirt and loose debris.
  - 3. Do not spall edges of brick or other masonry units or widen joints. Replace or patch damaged brick or other masonry units as directed by Architect.
- D. Notify Architect of unforeseen detrimental conditions including voids in mortar joints, cracks, loose masonry units, rotted wood, rusted metal, and other deteriorated items.
- E. Pointing with Mortar:
  - 1. Rinse joint surfaces with water to remove dust and mortar particles. Time rinsing application so, at time of pointing, joint surfaces are damp but free of standing water. If rinse water dries, dampen joint surfaces before pointing.
  - 2. Apply pointing mortar first to areas where existing mortar was removed to depths greater than surrounding areas. Apply in layers not greater than 3/8 inch until a uniform depth is formed. Fully compact each layer, and allow it to become thumbprint hard before applying next layer.
  - 3. After deep areas have been filled to same depth as remaining joints, point joints by placing mortar in layers not greater than 3/8 inch. Fully compact each layer and allow to become thumbprint hard before applying next layer. Where existing masonry units have worn or rounded edges, slightly recess finished mortar surface below face of masonry to avoid widened joint faces. Take care not to spread mortar beyond joint edges onto exposed masonry surfaces or to featheredge the mortar.
  - 4. When mortar is thumbprint hard, tool joints to match original appearance of joints as demonstrated in approved mockup. Remove excess mortar from edge of joint by brushing.
  - 5. Cure mortar by maintaining in thoroughly damp condition for at least 72 consecutive hours, including weekends and holidays.
  - 6. Hairline cracking within mortar or mortar separation at edge of a joint is unacceptable. Completely remove such mortar and repoint.
- F. Where repointing work precedes cleaning of existing masonry, allow mortar to harden at least 30 days before beginning cleaning work.

### 3.3 FINAL CLEANING

- A. After mortar has fully hardened, thoroughly clean exposed masonry surfaces of excess mortar and foreign matter; use wood scrapers, stiff-nylon or -fiber brushes, and clean water, applied by low pressure spray.
  - 1. Do not use metal scrapers or brushes.
  - 2. Do not use acidic or alkaline cleaners.

END OF SECTION 040121