



REINFORCEMENT SCHEDULE	
R1	#5 BARS @ 10" O.C. VERT. #4 BARS @ 10" O.C. HORIZ.
R2	#5 BARS @ 8" O.C. VERT. #4 BARS @ 10" O.C. HORIZ.
R3	#5 BARS @ 12" O.C. VERT. #4 BARS @ 10" O.C. HORIZ.
R4	#4 BARS @ 12" O.C. EF. VERT. #4 BARS @ 12" O.C. EF. HORIZ.
R5	#5 BARS @ 10" O.C. VERT. #4 BARS @ 12" O.C. HORIZ.
R6	#4 BARS @ 12" O.C. VERT. #4 BARS @ 12" O.C. HORIZ.

1. VERIFY ALL PANEL AND OPENING DIMENSIONS W/GENERAL CONTRACTOR & ARCHITECT PRIOR TO CASTING PANELS W/DOORS AND WINDOWS.
2. PROVIDE 1-HS E.F. AROUND PERIMETER OF PANEL U.N.O.
3. CUSHION REINFORCING THROUGH KNOCK-OUT OPENINGS.
4. BLOCKING AT TOP OF WALL TO REMAIN AFTER CONSTRUCTION OF PANELS.
5. HORIZONTAL STEEL CONTINUES THROUGH PANEL LEGS AT ALL OPENINGS.