



1. VERIFY ALL PANEL AND OPENING DIMENSIONS W/GENERAL CONTRACTOR & ARCHITECT PRIOR TO CASTING PANELS W/DOORS AND WINDOWS.
2. PROVIDE 1-W5 E.F. AROUND PERIMETER OF PANEL U.O.
3. CONTINUE REINFORCING THROUGH KNOCK-OUT OPENINGS.
4. BLOCKING AT TOP OF WALL TO REMAIN AFTER CONSTRUCTION OF PANELS.
5. HORIZONTAL STEEL CONTINUES THROUGH PANEL LEGS AT ALL OPENINGS.