



NOTES:

1. VERIFY ALL PANEL AND OPENING DIMENSIONS W/GENERAL CONTRACTOR & ARCHITECT PRIOR TO CASTING PANELS W/DOORS AND WINDOWS.
2. PROVIDE 1-#5 E.F. AROUND PERIMETER OF PANEL U.N.O.
3. CONINUE REINFORCING THROUGH KNOCK OUT OPENINGS.
4. BLOCKING AT TOP OF WALL TO REMAIN AFTER CONSTRUCTION OF PANELS.
5. HORIZONTAL STEEL CONTINUES THROUGH PANELS AT ALL OPENINGS.