


WALL FOOTING SCHEDULE		
MARK	FOOTING SIZE	FOOTING REINFORCEMENT
WF1	2'-0" x 3'-2"	3 - #4 CONT. TOP & BOT. 1/4" #3 TIES @ 60" O.C.
WF2	3'-6" x 3'-2"	5 - #4 CONT. TOP & BOT. 1/4" #3 TIES @ 24" O.C.
WF3	3'-6" x 3'-2"	SEE DETAIL 5/F2.2

COLUMN FOOTING SCHEDULE		
MARK	FOOTING SIZE	FOOTING REINFORCEMENT
FS.50	5'-6" x 5'-6" x 1'-0"	6 - #5 E.H. BOT.
FS.75	5'-6" x 5'-6" x 1'-0"	6 - #5 E.H. BOT.
FS.80	16'-0" x 16'-0" x 3'-4"	18 - #8 E.H. TOP & BOT.

OVERALL FOUNDATION PLAN

- SCALE: NONE
- NOTES:
- FINISH FLOOR REFERENCE ELEVATION = 100'-0".
 - TOP OF INTERIOR COLUMN FOOTING ELEVATION = 99'-0" U.N.O.
 - TOP OF EXTERIOR FOOTING ELEVATION = 99'-0" U.N.O.
 - COORDINATE ALL DOOR OPENINGS AND LOCATIONS WITH ARCHITECTURAL DRAWINGS.
 - VERIFY LOCATION OF ALL FOOTING STEPS WITH PANEL DRAWINGS PRIOR TO CASTING FOOTINGS.
 - INDICATES 10 MIL. VAPOR BARRIER UNDER SLAB ON GRADE. REINFORCE WITH 1/4" #4-HORIZ/24" x 2'-0".
 - VERIFY LOCATION OF BLOCK OUTS FOR DOWNSPOUTS WITH PLUMBING DRAWINGS PRIOR TO CASTING FOOTINGS.
 - 8" CMU RENF. 1/4" #4 @ 24" O.C. FULL HEIGHT. SEE DETAIL SHEET F2.2.
 - PROVIDE DOCK BASKETS @ ALL SLAB JOINTS. PROVIDE JOINT FILLER IN SPEED BAY JOINTS ONLY.



OVERALL PLAN FOR
REFERENCE ONLY.
USE SHEETS F1.1 TO F1.2
FOR WORKING DWGS